![NB NORTH BAYOU logo]

INSTALLATION INSTRUCTION

CF100
Multi-functional and professional mobile stand
For smart TV panels: 60"-100"
Maximum load capacity: 300 lbs / 136.4 kg
AV shelf max load: 25 lbs / 11.4 kg
Video tray max load: 10 lbs / 4.5 kg
VESA:200x200–1000x600mm

Table of Contents

WARNING !

Severe personal injury and property damage can result from improper installation
or assembly. Read the following warning carefully before beginning.

- If you do not understand the instructions or have any concerns or questions,
  please contact a qualified local installer.
- Do not install or assemble if the product or hardware is damaged or missing,
  if you require replacement parts, please contact your local distributor for assistance.
- This product fits most 60"-100" LCD/plasma screen; maximum weight of LCD/plasma
  screen:300lbs/136.4kg;AV shelf max load:25lbs/11.4kg;Video tray max load:10lbs/4.5kg.
- Do not use this product for anything other than the original design.
- This product contains moving parts, please use with caution.
- The manufacturer disclaims any liability for the modifications, improper installation,
  or installation over the specified weight range. The manufacturer will not be liable for
  any damages arising out of the use of, or inability to use, the product.

► All images are for reference, to prevail in product.

Manual

| Tightening Direction	Loosening Direction	Phillips Screwdriver	Metre Rule	Adjustment	By Hand	Hex Wrench	+ Tightening − Loosening

Parts List

1X	2X	1X
1X		1X
		2X
		2X

1X	1X	1X	1X	1X	2X
2X					2X

A 4X	B 4X	C 4X	D 4X	E 4X	F 4X
M5×25mm	M6×25mm	M8×25mm	M10×15mm	Φ16×Φ6.2×1.5mm	Φ 19×8.5×H13mm

G 8X	H 8X	I	J	K 2X
M8×40mm	M6×25mm	M5	M6	Φ 16×12.5×T2mm

# 1. Base extension adjustment and wheels installation

Step 1:
Take sheet foam from box and lay it on floor.

Step 2:
Put base upside down on sheet foam.

1   # 2

Step 3

I

550mm Before extension

Step 4

I

750mm afternoon extension

Step 5

1   # 2

Step 6

Match these numbers

②
②

Warning: ⚠
Ensure screws are secured firmly.

Step 7

I

H

Step 8

Step 9

K   K

Step 10
Turn base back to normal and move away from sheet foam

2. Alu columns adjustment

Step 1
Put a column on sheet foam

Column 1

Step 2
Release screw at side

I

Step 3
Pull inner column out to your desire height

In step of 50mm

Step 4

Step 5
Repeat step 1 to 4 on the other column 2

Column 2

3. TV interface tilt heads to columns installation

Column 1

Step 1

I

Step 2

Step 3

Step 4

Step 5

I

**Warning:** ⚠️
Ensure screws are
secured firmly.

Step 6
Repeat step 1 to 5 on column 2

Column 2

Step 1

Must be same height

Step 2

J

G

Warning: ⚠️
Ensure screws are secured firmly.

Step 3

Step 4

I

H

Step 1

Step 2

**Warning:** ⚠️
Ensure screws are
secured firmly.

Step 3

Step 4

Note:
To adjust shelf height, simply
 loosen 4X screws at sides
 and tighten firmly after set.

Step 5

Step 1

Must be same height

Locking biade

Step 2

Caution :
Before put on interface plate,
loclcing blade should be
pointed upward.

Step 3

Note :
Moves TV interface
to center.

Step : If required height needs to be lower down, need 2 men. One man holds onto interface assembly, the other release screw at side, and slide stopper catch backward and hold, 1st man allow interface assembly slide down slowly until the desired height, free stopper catch and it will back to Its original place. Tighten screw.

**Warning**: Be sure the stopper catch rest at palace.

Figure 1

Stopper catch

In step of 50mm

Figure 2

68.5"(1740mm)

54.7"(1390mm)

I

Figure 3

Jammed screw

8. VESA mounting patterns

VESA: 200×200-1000×600

7.87"(200mm)

7.87"(200mm)

11.8"(300mm)

11.8"(300mm)

15.7"(400mm)

7.87"(200mm)

15.7"(400mm)

15.7"(400mm)

23.6"(600mm)

15.7"(400mm)

31.4"(800mm)

15.7"(400mm)

31.4"(800mm)

19.6"(500mm)

39.3"(1000mm)

23.6"(600mm)

Step 1

Note :
To avoid damage plastic spacers must be used when depth of mounting holes is at minimal.

!

F
E
(A/B)+E+F/C+F/D

M5x25mm (A)
M6x25mm (B)

M8x25mm (C)

M10x15mm (D)

Cautions

Step 2

Step 1

Note:
Moves TV to center.

Warning:
Need 2 men to hook on
TV to avoid accident.

Step 2

Warning:
Ensure screws are
secured firmly.

Pad lock not supplied

Step 1

Step 2

Step 3
Release 2 screws

Step 4

Step 5

Step 6

Step 7

Step 8

Step 9

Step 10

Note:
Adjustable height.

Warning: ⚠
Ensure screws are secured firmly.

Note:
Be caution when routing wires to avoid damage.